



## **Operating instructions**

# **Soft impact core drilling machine SID352/PRO**

BA-01-000006-05-EN



### Scope of application

These Operating instructions only apply to the machine designated on the cover sheet.

Check the machine model using the machine's rating plate.

### Original instructions / translation of the original instructions

The German copy of these Operating instructions is the original instructions in accordance with the EU Machinery Directive.

Copies in other languages are translations of the original instructions.

**Kernlochbohrer GmbH**

**Geigersbühlweg 52**

**72663 Großbettlingen**

**Germany**

**Phone: +49 (0)70 22 / 50 34 900**

**E-mail: [info@kernlochbohrer.com](mailto:info@kernlochbohrer.com)**

**Internet: <http://www.kernlochbohrer.com>**

© Kernlochbohrer GmbH

This documentation is protected by copyright.

All rights to this documentation, in particular the right of reproduction, distribution and translation, are reserved by Kernlochbohrer GmbH, even in the case of applications for industrial property rights. No part of this documentation may be reproduced in any form by any means, electronic or mechanical, or processed, copied or distributed using electronic systems without the express written permission of Kernlochbohrer GmbH.

Subject to errors and technical changes.

Kernlochbohrer GmbH is not liable for any errors in this documentation. Liability for direct or indirect damages arising in connection with the delivery or use of this documentation is excluded to the extent permitted by law. Furthermore, Kernlochbohrer GmbH cannot be held liable for damages resulting from the infringement of patent and other rights of third parties.

The function of the machine is limited to the functions described in the associated technical documentation.

**Table of contents**

1	Information and support .....	6
1.1	Thanks to the buyer.....	6
1.2	Using the Operating instructions .....	6
1.3	Changes .....	6
1.4	Explanation of symbols .....	7
1.5	Warranty .....	7
1.6	Environmental protection.....	8
1.6.1	Disposal of the product.....	8
1.6.2	Disposal of the packaging .....	8
1.7	Service .....	9
2	Security.....	10
2.1	General information.....	10
2.2	Intended use.....	11
2.3	Safety regulations for the operator .....	12
2.3.1	Organizational security measures .....	12
2.3.2	Changes to the machine.....	12
2.3.3	Spare parts .....	13
2.3.4	Personnel.....	13
2.4	Safety regulations for staff.....	14
2.4.1	Safety-oriented behavior .....	14
2.4.2	Safe operation .....	15
2.4.3	Protective equipment.....	16
2.5	Safety during maintenance.....	17
2.5.1	General information .....	17
2.5.2	Cleaning.....	17
3	Technical data .....	18
4	Machine description .....	19
4.1	Machine components .....	19
4.2	Protective devices .....	23

4.2.1	Mechanical overload protection .....	23
4.2.2	Electronic overload protection .....	23
4.2.3	Overvoltage protection .....	24
4.2.4	Overheating protection .....	24
4.2.5	Carbon brush warning system .....	24
4.3	Scope of delivery .....	25
5	Use of the machine .....	26
5.1	Specific precautions .....	26
5.2	Transportation of the machine .....	27
5.3	Working with the machine .....	27
5.3.1	Visual inspection of the machine .....	27
5.3.2	Attach drill bit to machine .....	28
5.3.3	Attaching the machine to the core drill rig .....	29
5.3.4	Establish water supply to the machine .....	30
5.3.5	Establish dust extraction of the machine .....	31
5.3.6	Establish electrical connection of the machine .....	31
5.3.7	Using the machine .....	33
5.3.8	Switch off the machine .....	36
5.3.9	Store the machine .....	36
6	Maintenance .....	37
6.1	Notes on proper maintenance .....	37
6.2	Maintenance and inspection plan .....	37
6.3	Inspection and maintenance .....	38
6.3.1	Clean the machine and check .....	38
6.3.2	Check the condition of the transmission oil .....	40
6.3.3	Replacing carbon brushes .....	41
7	Troubleshooting .....	42
8	Spare parts .....	45
9	EU Declaration of Conformity .....	48

# **1 Information and support**

## **1.1 Thanks to the buyer**

Thank you for purchasing a machine from Kernlochbohrer GmbH.

Please read the Operating instructions carefully and observe the safety instructions. By following the Operating instructions, you will be able to take full advantage of the outstanding performance of our product.

If you have any questions regarding the operation of the machine, please contact Kernlochbohrer GmbH directly. We are available to answer your questions at any time.

## **1.2 Using the Operating instructions**

The machine is intended for professional use and may only be operated by trained personnel. Strictly adhere to the instructions in the Operating instructions.

Our company declines all responsibility if the Operating instructions are not observed, which may result in injury or damage to the machine.

The Operating instructions are indispensable for using the machine. The Operating instructions must therefore always be kept close to the machine and be accessible to the intended personnel at all times.

In addition to the Operating instructions, the generally applicable and local regulations for accident prevention and environmental protection must be provided; compliance with these regulations must be checked regularly.

## **1.3 Changes**

Kernlochbohrer GmbH reserves the right to change the design and appearance of the products and their Operating instructions. Future changes to the Operating instructions will be made without prior notice.

## 1.4 Explanation of symbols



This symbol draws your attention to dangers that you must be aware of when carrying out the following work in order to avoid injury to yourself, other persons or damage to property.



Cross-reference to another point in the Operating instructions.



Prerequisite for an action.



Action to be performed.



Behavior of the machine that is to be expected as a result of the preceding action.



Background information or reference to special features.

## 1.5 Warranty

In accordance with Kernlochbohrer GmbH's general terms of delivery, a warranty period of 12 months applies for material defects in business transactions with companies (proof by invoice or delivery bill).

Damage caused by natural wear and tear, overloading or improper handling is excluded.

Damage caused by material or manufacturer defects will be rectified free of charge by repair or replacement. Complaints can only be accepted if the device is sent to Kernlochbohrer GmbH undismantled.

Wear parts are excluded from the warranty.

## **1.6 Environmental protection**

### **1.6.1 Disposal of the product**

Follow national regulations on environmentally friendly disposal and recycling of used machines and accessories.

For EU countries only:

Do not dispose of the machine with household waste! In accordance with European Directive 2012/19/EU on waste electrical and electronic equipment and its transposition into national law, used power tools must be collected separately and recycled in an environmentally friendly manner.

### **1.6.2 Disposal of the packaging**

The packaging is made of recyclable materials. They must be disposed of in accordance with their labeling and municipal guidelines.

## 1.7 Service

Precise information and specific questions allow faults to be rectified quickly, make it easier to order spare parts and prevent incorrect deliveries.

Before contacting the service, please collect the following data first.

The model designation must be stated for all questions and orders. This information can be found on the type plate of the machine.

In the event of malfunctions, further information is required: type and extent of the malfunction, accompanying circumstances, suspected cause.

When ordering spare parts, the following is required: Quantity and item number in the exploded drawing in these Operating instructions.

- ① You are welcome to send us photos when ordering spare parts or videos in the event of faults.

Contact details:

Kernlochbohrer GmbH

Geigersbühlweg 52

72663 Großbettlingen

Germany

Phone: +49 (0)70 22 / 50 34 900

E-Mail: [info@kernlochbohrer.com](mailto:info@kernlochbohrer.com)

Internet: <http://www.kernlochbohrer.com>

## **2 Security**

### **2.1 General information**

The machine was built according to the state of the art and in compliance with the applicable laws, standards and safety regulations. Nevertheless, the use of the machine can result in hazards for the user or third parties as well as damage to the machine and other property.

The machine may only be used if it is in perfect working order and in accordance with its intended use and in a safe and hazard-conscious manner.

If the machine is damaged or malfunctions, switch it off immediately, secure it against being switched on again and repair it or arrange for it to be repaired.

## **2.2 Intended use**

The machine is designed exclusively for drilling concrete, reinforced concrete, stone, masonry and similar materials with the appropriate core bits using wet or dry drilling methods.

The machine may only be used together with an appropriate core drill rig. The machine is not suitable for hand-held drilling.

Ensure that a core bit suitable for the drilling technique and the material to be drilled is always used. The machine must be connected to a dust extraction system or a water supply to ensure optimum service life of the core bit.

The machine may only be used within the limits of its technical data. This information, for example performance data and ambient conditions, can be found in the "Technical data" chapter.

Any other use or use beyond this is considered improper use - risk of accident! Kernlochbohrer GmbH is not liable for any resulting damage. The risk is borne solely by the operator. In order to be able to determine in the event of damage whether the damage was caused by improper use, overload conditions are permanently recorded by the machine.

Intended use also includes observing the operating instructions and complying with the prescribed maintenance intervals.

## **2.3 Safety regulations for the operator**

### **2.3.1 Organizational security measures**

The Operating instructions must always be available for the operating and maintenance personnel. It must therefore always be kept at the machine's place of use.

The regulations on accident prevention and environmental protection applicable at the machine's place of use must also be available. The operator of the machine must regularly check that they are complied with.

The use of sound-emitting machines may be limited in time by national or local regulations.

The machine must not be operated in potentially explosive atmospheres or in the vicinity of flammable liquids or gases or combustible dust.

All safety and danger notices on the machine must be legible and must not be removed.

The protective equipment required to operate the machine must be provided by the operator. The operator must ensure that the protective equipment is used properly by the personnel.

Operating and auxiliary materials, such as lubricants or cleaning agents, must be selected in such a way that the limit values for hazardous substances applicable at the place of use are complied with. The regulations for environmental protection and disposal applicable at the place of use must be complied with.

### **2.3.2 Changes to the machine**

The operator may not make any modifications to the machine without written approval from Kernlochbohrer GmbH. If the operator carries out modifications without authorization, the warranty becomes void. Kernlochbohrer GmbH is not liable for damage caused by unauthorized modifications.

### **2.3.3 Spare parts**

Spare parts must comply with the properties defined by Kernlochbohrer GmbH. This is always guaranteed for spare parts supplied by Kernlochbohrer GmbH. Kernlochbohrer GmbH is not liable for damage caused by the use of unsuitable spare parts.

### **2.3.4 Personnel**

All persons entrusted with the commissioning, operation and maintenance of the machine must have read and understood the Operating instructions beforehand.

The machine may only be operated by persons who have been adequately instructed beforehand.

The machine may only be serviced by persons who have completed the appropriate specialist training for this activity.

Minors are not permitted to work with the machine. Young people over the age of 16 who are trained under supervision are exempt from this regulation.

## **2.4 Safety regulations for staff**

### **2.4.1 Safety-oriented behavior**

All persons responsible for commissioning, operating and maintaining the machine must have read and understood the Operating instructions beforehand.

The machine may only be operated by persons who have been adequately instructed beforehand.

The machine may only be serviced by persons who have completed the appropriate specialist training for this activity.

Minors are not permitted to work with the machine. Young people over the age of 16 who are trained under supervision are exempt from this regulation.

Any work on and with the machine that impairs safety must be avoided.

All safety and danger notices on the machine must be legible and must not be removed.

## **2.4.2 Safe operation**

Operating the machine requires the full concentration and ability of the personnel. Persons who are overtired, unable to concentrate or under the influence of alcohol, drugs or medication must not work on or with the machine.

Persons who are not directly required to operate the machine must maintain a sufficient safety distance from the machine.

Before using the machine, check that it is in perfect condition. If the machine is damaged, it must not be used. Then secure the machine against use and repair it or arrange for it to be repaired.

In order not to jeopardize the functionality and safety of the machine, covers or other components of the machine must not be removed.

Before starting or starting up the machine, ensure that persons are not endangered by the starting machine.

Operating elements must not be operated thoughtlessly or willfully. This could result in personal injury or damage to the machine.

When using the machine, staff must ensure that they stand securely and adopt an ergonomic posture.

The machine must not be left unattended during use.

Stopping the machine during operation with a heavy load must be avoided. This could lead to damage due to overheating.

Air inlet and outlet openings must not be covered during use.

The machine must not be exposed to rain or moisture and must never be immersed in water. Water entering the machine increases the risk of electric shock.

The machine must be cleaned regularly so that dirt does not accumulate. All operating elements and handles must be kept clean, dry and free of grease.

When the machine is not in use, it must be parked in such a way that nobody is endangered. Secure the machine against unauthorized use.

### **2.4.3 Protective equipment**

Persons using the machine are obliged to wear the following protective equipment:

- Safety goggles according to standard EN 166 or face protection.
- Suitable hearing protection.

The generation of harmful drilling dust must be prevented by technical means (wet process or dry process with dust extraction). If this is not possible, the operating personnel and bystanders must always wear a respirator approved for the material being processed.

Wearing additional protective equipment reduces the risk of injury:

- Safety shoes with non-slip sole and protective toe cap.
- Cut-resistant and non-slip gloves.
- Safety helmet

Loose-fitting clothing, long hair or body jewelry can get caught on moving parts of the machine!

Persons carrying out maintenance work on the machine are obliged to wear the appropriate protective equipment required for this work.

## **2.5 Safety during maintenance**

### **2.5.1 General information**

The machine may only be maintained by persons who have completed the appropriate specialist training for this activity.

The maintenance activities and intervals specified in the Operating instructions must be observed.

Workshop equipment appropriate to the type of work is required to carry out maintenance activities.

The following safety precautions must be taken before starting maintenance work:

- Position the machine so that the access point is easily accessible.
- Set the machine to the appropriate operating status.

After completion of maintenance activities:

- Assemble the machine completely.
- If operating elements or safety devices have been removed, they must be refitted and their function checked.
- Retighten any screw connections that have been loosened. Re-attach the screw locks.

Persons carrying out maintenance work on the machine are obliged to wear the appropriate protective equipment required for this work.

### **2.5.2 Cleaning**

Do not use any corrosive, harmful or environmentally damaging substances to clean the machine. Dispose of cleaning agents in an environmentally friendly manner.

Under no circumstances should high-pressure cleaners, water jets or compressed air be used to clean the machine.

### 3 Technical data

Article number	6213		
Power consumption	3300 W		
Tension	230 V $\pm$ 5% / 50 Hz		
Power consumption	16 A		
Spindle thread	1 ¼" UNC & G ½"		
Gear	Speed	Num. of strokes ①	Max. Drill-Ø
1	512 1/min	12288 1/min	352 mm
2	1062 1/min	25488 1/min	202 mm
3	1576 1/min	37824 1/min	132 mm
Weight	18 kg		
Permissible ambient temperature	5°C to 40°C		
Permissible relative humidity	30% to 80%		
Protection class	IP 20		
Connector plug	Type F (CEE 7/4)		
Mains cable: Type   Length	G-HPMCE 3x 1.5 mm <sup>2</sup>   3 m		
Sound power level L <sub>weq</sub> at idle	98 dB(A)		
Water/dust connection	GEKA® -coupling 3/4"		
Water supply adapter	Gardena		
Dust extraction adapter	For hose Ø 35 mm		
Compatible core drill rig	IDS352/V-PRO or KBS352/PRO or KBS352/XL-PRO or KBS502/PRO		

① In soft impact drilling mode


## 4 Machine description

### 4.1 Machine components




#### Machine components

- 1 Drill spindle
- 2 Mode selection ring
- 3 Gearbox housing (aluminum)
- 4 Gear selector switch
- 5 Motor housing (glass fiber reinforced polyamide)
- 6 Transport handle
- 7 LCD display, on/off switch and LED warning indicators
- 8 Connection for water supply or dust extraction
- 9 Adapter for dust extraction
- 10 Interface for core drilling rig
- 11 Mains cable with personal protection circuit breaker (PRCD)
- 12 Carbon brush holder cover




Rear of the machine

- 1 Power level lights (4 pieces)
- 2 LCD display
- 3 On/off switch
- 4 LED "🔧" (overheating protection)
- 5 Overload" LED



Indications on the LCD display

- 1 Tension
- 2 Motor temperature
- 3 Operating hours
- 4 Normal
- 5 Power consumption
- 6 Power consumption
- 7 Alarm
- 8 Overheating protection
- 9 Carbon brush replacement
- 10 Overvoltage protection
- 11 Electronic overload protection



### Setting drilling mode

- 1 Drill spindle
- 2 Mode selection ring
- 3 Normal drilling mode (symbol ④ )
- 4 Soft impact drilling mode (symbol ⑤ )



Personal protection circuit breaker (PRCD)

## **4.2 Protective devices**

### **4.2.1 Mechanical overload protection**

This machine is equipped with a mechanical slip clutch to protect the operator and the machine from excessive torque forces. If the drill bit suddenly jams in the hole, the safety clutch is triggered and the drill spindle stops

The slipping clutch must not be loaded for longer than 3 to 4 seconds. If the slipping clutch is activated during the drilling process, the feed pressure must be reduced immediately. Otherwise, the safety clutch may be destroyed due to the high level of wear. Once the drill bit has returned to normal speed, the drilling process can be continued.

### **4.2.2 Electronic overload protection**

There are 2 LED indicators below the machine's on/off switch.

If the machine is in an overload state, the red LED labeled "Overload" lights up and the corresponding indicator and alarm symbol light up on the LCD display. This signals to the operator that the maximum power supply has been reached. The feed pressure must then be reduced immediately until the red LED and the indicator in the LCD display go out.

If the machine is operated in an overload state for a longer period of time, the machine switches off for its own protection and the red LED lights up permanently. Shutting down the machine due to an overload constitutes improper use and can result in the warranty for the machine being voided.

After shutting down the machine due to an overload, disconnect the machine from the mains and carry out the following checks:

- Drill bit not jammed in the hole?
- Gear selector engaged in the desired position?
- Can the drill bit rotate normally?

The machine can then be restarted.

### **4.2.3 Overvoltage protection**

The machine can absorb short-term voltage peaks of up to a maximum of 260 volts. Higher voltages can cause irreparable damage, which is why the machine switches off for its own protection.

Please note that if the machine is operated with a generator, it must not exceed the maximum specified value.

If the overvoltage protection is triggered during operation of the machine, the corresponding indicator and the alarm symbol light up on the LCD display. The machine switches off or cannot be put into operation. The power supply must then be checked and replaced if necessary.

### **4.2.4 Overheating protection**

If the temperature of the machine's motor becomes too high, the built-in thermal protection switch is activated and the machine switches off to protect itself. At the same time, the yellow LED light labeled "⚡" above the on/off switch lights up and the corresponding indicator and alarm symbol light up on the LCD display.

If the overheating protection is triggered during operation of the machine, the machine must not be restarted immediately. The machine must first cool down for approximately 2 to 3 minutes.

### **4.2.5 Carbon brush warning system**

When the carbon brushes have almost reached the end of their service life, the machine switches off automatically to protect the motor from further damage.

If both the red and yellow LEDs light up and the symbol for replacing the carbon brushes is shown on the LCD display, the carbon brushes must be checked and replaced if necessary. The carbon brushes must only ever be replaced as a pair.

 See chapter 6.3.3 "Replacing carbon brushes".

### 4.3 Scope of delivery

The scope of delivery of the machine includes the following components:

- Soft impact core drilling machine SID352/PRO
- Adapter for water supply
- Adapter for dust extraction
- Easy-release ring
- Open-end wrench SW 32 and SW 41
- Set (2 pieces) of replacement carbon brushes
- Pair of earplugs
- Safety goggles
- Operating instructions

① The core drill rig required to use the machine must be purchased separately.

Kernlochbohrer GmbH offers an extensive range of tools and accessories for the machine:

- Core drill rig
- Drill bits
- Adapter for core bits
- Quick-change systems for core bits
- Water collection rings

The webshop <http://www.kernlochbohrer.com> is available for information and ordering.

## 5 Use of the machine

### 5.1 Specific precautions



#### Risk of injury!

When operating the machine, persons must always keep a sufficient distance.

Rotating parts of the machine and falling or splashing particles can cause injuries.



#### Danger of electric shock!

The machine does not have the appropriate degree of protection and must therefore not be operated in the rain or in wet rooms (e.g. bathrooms or laundry rooms).

Only use core bits whose cutting segments are sharp and undamaged. Sharp drill bits do not tilt as quickly when drilling and are easier to guide.

When using the machine for drilling vertically upwards, a functional water collection ring must be used. Water must not be allowed to reach the machine.

Before starting the drilling process, the intended exit point of the drill bit must be inspected. The exit point must be secured and shut off. It must be ensured that no personal injury or material damage is caused by the escaping drill bit.

If a fault occurs during operation of the machine (e.g. smell of burning), switch off the machine immediately and disconnect the mains cable from the plug. Otherwise a fire, electric shock or other incident could occur. The machine may only be switched on again once the fault has been rectified and the machine is functioning correctly.

## **5.2 Transportation of the machine**

Before transporting the machine:

- Switch off the machine.
- Remove the mains cable from the socket.
- Disconnect the water supply or back pressure suction.

## **5.3 Working with the machine**

### **5.3.1 Visual inspection of the machine**

Before working with the machine, it must be visually inspected:

- Check the general condition and cleanliness of the machine.
- Check that all covers and machine components are present.
- Check that all screws are tight.
- Air inlet and outlet openings must not be dirty or covered.
- The mains cable and mains plug must not be damaged.

### 5.3.2 Attach drill bit to machine

A drill bit is a cylindrical tool that is fitted with soldered or laser-welded cutting segments.

To mount the drill bit on the machine, the drill spindle is equipped with a 1 ¼" UNC external thread and a G ½" internal thread.

- ① Appropriate adapters are available for drill bits with different threads.

To prevent corrosion and to facilitate disassembly of the core bit, a water-resistant grease can be applied to both threads before assembly.

- ① A quick-change system can be used to change core bits quickly and easily.

Alternatively, the supplied easy-release ring can be used to easily detach the drill bit from the drill spindle.




Risk of injury from sharp-edged cutting segments of the drill bit!  
Wear cut-resistant gloves!

#### Auxiliary means:

Water-resistant lubricating grease

Open-end wrench with width across flats SW 32 and SW 41

#### Prerequisites:

- Machine not connected to the power supply.
- Visual inspection of the machine carried out.
  -  See chapter 5.3.1 "Visual inspection of the machine".

**Procedure:**

- ☒ If necessary, apply a thin layer of water-resistant grease to the internal thread of the drill bit and the external thread of the machine's drill spindle.
- ☒ Screw the drill bit onto the drill spindle of the machine and tighten hand-tight.
- ☒ Tighten the drill bit with an open-end wrench SW41 while holding the drill spindle of the machine with an open-end wrench SW32.

**5.3.3 Attaching the machine to the core drill rig**

Risk of injury!

The machine may only be used on a core drill rig! The machine is not suitable for hand-guided drilling.

- ① The core drill rig required to use the machine must be purchased separately.

Kernlochbohrer GmbH offers an extensive range of tools and accessories for the machine. The webshop <http://www.kernlochbohrer.com> is available for information and ordering.

Before working with the machine, the core drill rig must be secured in the drilling position.

The machine must not be attached to the core drill rig.



Information on attaching the core drill rig can be found in its Operating instructions.

**Prerequisites:**

- ☑ Machine not connected to the power supply.
- ☑ Visual inspection of the machine carried out.
- ☑ Core drill rig attached to the drilling position and aligned.
- ☑ Drill bit mounted on the machine.
  - 📖 See chapter 5.3.2 "Attach drill bit to machine".

**Procedure:**

- ☒ Attach the machine to the core drill rig.
  - ① The machine is attached to the core drill rig with four hexagon socket screws (M8x35) and a feather key (10x8x100). This fastening material is included in the scope of delivery of the core drill rig.
  - 📖 Information on mounting the machine on the core drill rig can be found in its Operating instructions.

**5.3.4 Establish water supply to the machine**

- ① The machine can be used for wet or dry drilling.

In the wet drilling process, the water is used to cool the drill bit so that it does not heat up excessively during drilling, which would cause increased wear.
- ① Only clean water may be used.

Only clean and dust-free hoses and couplings may be used.  
The maximum water pressure must not exceed 3 bar.
- ① When using the machine for wet drilling, we recommend the use of an additional water collection ring to protect the machine and the working environment.

Kernlochbohrer GmbH offers an extensive range of tools and accessories for the machine. The webshop <http://www.kernlochbohrer.com> is available for information and ordering.

**Procedure:**

- ☒ Attach the water connection to the machine interface.
- ☒ Close the ball valve on the water connection (in the transverse position).
- ☒ Connect the machine's quick-release coupling to a water hose.

**5.3.5 Establish dust extraction of the machine**


- ① The machine can be used for wet or dry drilling.  
When dry drilling, the drilling dust produced must be removed using a suitable industrial vacuum cleaner.

**Procedure:**

- ☒ Attach the vacuum cleaner connection to the machine interface.
- ☒ Attach the industrial vacuum cleaner to the vacuum cleaner connection.

**5.3.6 Establish electrical connection of the machine**

Please note the following points:

- Observe the electrical connection values of the machine.  
 See chapter 3 "Technical data".
- Before connecting the machine to the power supply, ensure that the machine is switched off.
- The mains cable and mains plug must not be damaged.
- Damaged mains plugs may only be replaced by Kernlochbohrer GmbH or a qualified electrician.
- The machine is equipped with a type F mains plug (CEE 7/4). The machine may only be operated from an earthed socket (CEE 7/3) that is appropriately earthed.

- To protect the operator and reduce the risk of electric shock, the machine is equipped with a personal protection circuit breaker (PRCD) integrated into the mains cable. The machine may only be connected to the mains using this personal protection circuit breaker.
- After plugging the mains plug into the socket, the personal protection switch must be subjected to a test run. If the personal protection switch does not trip, the machine must be disconnected from the mains again and checked by a qualified electrician.
- Never touch the mains plug with wet hands.
- The mains plug and socket must be clean and dust-free.
- The supplied electrical voltage must not deviate by more than 5% from the nominal value. Excessive voltages can lead to irreparable damage to the machine.
- Voltage peaks must not occur when operating the Core drilling machine with power generators.
- When using extension cables, the cable cross-section must be suitable for the power consumption of the machine.
- When using a cable reel, the cable must always be unrolled completely.
- If the machine is used outdoors with an extension cable, the extension cable must be approved for outdoor use.
- Grasp the mains plug to remove the mains cable from the socket. Do not pull on the power cable.
- Do not use the power cable to pull or transport the machine and keep it away from heat, solvents and oils, sharp edges and moving parts.
- If the machine is not to be used for a longer period of time, switch off the machine and remove the mains plug from the socket.

### 5.3.7 Using the machine






Before starting or starting up the machine, ensure that tools used to mount the drill bit have been removed from the drill spindle.



#### Auxiliary means:

Open-end wrench with width across flats SW 32

#### Prerequisites:

- ☑ Visual inspection of the machine carried out.
- ☑ Core drill rig attached and aligned.
- ☑ Drill bit mounted on the machine.
- ☑ Machine attached to the core drill rig.  
 See chapter 5.3.3 "Attaching the machine to the core drill rig".
- ☑ Water supply or dust extraction of the machine.  
 See chapter 5.3.4 "Establish water supply to the machine" or chapter 5.3.5 "Establish dust extraction of the machine".
- ☑ Electrical connection of the machine established.  
 See chapter 5.3.6 "Establish electrical connection of the machine".


#### Procedure:

- ☒ Set the desired drilling mode using the mode selection ring on the spindle of the machine:
  - ☒ Press the mode selection ring in the direction of the arrow on the spindle.
  - ☒ Set the desired drilling mode by turning the mode selection ring:
    -  Normal drilling mode
    -  Soft impact drilling mode
- ⓘ The soft impact function is preferred if the machine is to be used for dry drilling.

- ☒ Set the desired speed on the machine's gear selector switch according to the drilling diameter.
  - 📖 See chapter 3 "Technical data".
- ① The specified drilling diameters and speeds of the machine are based on an average concrete hardness.

For reinforced concrete, a lower gear should be selected to reduce the speed.
- ① The gear selector switch may only be operated when the machine is switched off.

Turn the gear selector switch and allow it to engage in the desired position.


If the gear selector switch is stiff, turn the drill spindle slightly using an open-end wrench with a width across flats of 32 to enable gear selection.
- ☒ Perform a function test of the personal protection circuit breaker (PRCD):
  - ☒ Hold the personal protection switch in your hand and press the "TEST" button with your bare finger. Do not use gloves or other insulating objects.
  - ↪ As soon as the personal protection switch is switched on, the electronics check whether the protective earth conductor (PE) is free of mains voltage.
  - ☒ Switch off the personal protection switch by pressing the "RESET" button.
  - ☒ Switch the personal protection switch on again by pressing the "TEST" button.
  - ↪ The machine must now be able to be operated.
-  If the personal protection switch does not trip or repeatedly switches off when the machine is switched on, the entire combination must be checked by a qualified electrician.

Use of the machine in this condition is not permitted!
- ☒ Switch the machine on at the on/off switch and let it run briefly: Check the concentricity of the drill bit.

- ☒ Switch on the machine at the on/off switch without load.
- ☒ If the machine is to be used for dry drilling:
  - ☒ Switch on the vacuum cleaner.
  - ☒ When the vacuum cleaner has built up the maximum vacuum: Carefully start drilling.
- ☒ If the machine is to be used for wet drilling:
  - ☒ Open the ball valve on the water connection
  - ☒ If water emerges continuously from the center of the drill bit: Start drilling carefully.
- ☒ When the cutting depth has reached 10 mm, the feed pressure can be increased.
  - ⓘ If the speed or feed pressure is too high when drilling, this can cause the drill bit to jam.
- ☒ During the drilling process, continuously observe the LED displays on the top of the motor housing:  
If the red 'Overload' LED lights up: Immediately reduce the feed pressure.
- ☒ Continuously monitor the speed of the machine during the drilling process:  
If the speed drops, reduce the feed pressure.
- ☒ If the machine is used for wet drilling:  
If the feed rate decreases at the same feed pressure and the water emerging from the hole becomes clearer but is mixed with metal chips, the drill bit has hit reinforcing steel.  
  
Reduce the feed pressure until the reinforcing bar is cut through.
- ☒ If wooden beams, thick asphalt or bitumen are cut through, the machine's power supply increases. Then reduce the feed pressure.
- ☒ If it is necessary to drill deeper than the effective length of the drill bit allows, an optional drill extension can be used.
- ☒ Continuously monitor the machine during the drilling process:  
If light smoke appears or the smell of an overloaded electric motor can be detected, relieve the machine and pull it out of the hole.  
Then continue drilling slowly and carefully.
- ☒ When the end of the through-hole is almost reached:  
Reduce the feed pressure until the core bit emerges on the opposite side.



### 5.3.8 Switch off the machine

#### Procedure:

- ☒ Switch off the machine motor by pressing the on/off switch.
- ☒ Close the ball valve and disconnect the water supply.  
Or:  
Switch off the vacuum cleaner and disconnect the dust extraction system.
- ☒ Remove the mains plug from the socket.
- ☒ Remove the machine from the core drill rig.
- ☒ Remove the core bit from the machine.
- ☒ Check the machine for soiling. Clean the machine if necessary.  
 See chapter 6.3.1 "Clean the machine and check".

### 5.3.9 Store the machine

#### Procedure:

- ☒ Machine switched off.  
 See chapter 5.3.8 "Switch off the machine".
- ☒ Clean the machine and allow to dry completely.  
 See chapter 6.3.1 "Clean the machine and check".
- ☒ Store the machine in a dry, cool place protected from moisture and direct sunlight.
- ☒ Secure the machine against unauthorized use.

## 6 Maintenance

### 6.1 Notes on proper maintenance

Insufficient or improper maintenance can cause malfunctions and impair the operational safety and service life of the machine. Regular inspection and maintenance is therefore essential. We recommend that maintenance work is only carried out by trained personnel.

The contractually agreed warranty does not release the operator of the machine from the obligation to maintain the machine in accordance with the manufacturer's instructions from the time of commissioning. Kernlochbohrer GmbH is not liable for damage caused by a lack of maintenance.

### 6.2 Maintenance and inspection plan

The interval specifications refer to normal operating conditions. In more difficult conditions (heavy dust accumulation, etc.) and longer daily working times, the specified intervals must be shortened accordingly by the operator.

Only use the maintenance and inspection schedule as a guide! Be sure to follow the cross-references to the other chapters! They describe in detail how to carry out the individual tasks correctly and safely.

Interval	Category	Component	Activity	Chapter
1 day	Real time	Machine	Cleaning and testing	6.3.1
200 hours	Operating time	Gearbox	Check transmission oil	6.3.2
200 hours ①	Operating time	Motor	Replacing carbon brushes	6.3.3

- ① This activity must be carried out after 200 hours of operation or after the carbon brush warning system responds.

## 6.3 Inspection and maintenance

### 6.3.1 Clean the machine and check



Do not use sharp sponges or metal objects to clean the machine. These could damage the surface of the machine.

Do not use high-pressure cleaners, water jets or compressed air to clean the machine. The sharp water or air jet could damage the machine.

No corrosive, harmful or environmentally damaging substances may be used to clean the machine.


#### Interval:

1 day real time

#### Auxiliary means:

- Container with a mixture of water and mild detergent (e.g. washing-up liquid).
- Cloth and brush
- Water-resistant lubricating grease

#### Procedure:

- Machine switched off and mains plug removed from socket.  
 See chapter 5.3.8 "Switch off the machine".
- Clean the machine to remove dust and dirt.
  - Use a damp cloth dipped in water mixed with a mild detergent.
  - Water must not be allowed to enter the interior of the machine via the air inlet and outlet openings.
- Clean the air inlet and outlet openings with a brush and damp cloth.
- Allow the machine to dry completely.
- Check the tightness of all bolts and nuts on the machine. If necessary, tighten the screws and nuts.

- ☒ Check the condition and effectiveness of the water seals. Replace damaged or worn water seals.
- ☒ Check the gearbox housing for oil leaks. If oil is leaking from the gearbox, contact Kernlochbohrer GmbH.
- ☒ Check the mains plug and mains cable for damage. Have damaged parts replaced by a qualified electrician.
- ☒ Carry out a test run of the personal protection circuit breaker (PRCD). If the PRCD does not trip during the test run, have the appliance checked by a qualified electrician.
- ☒ Apply a thin layer of water-resistant grease to the external thread of the machine's drill spindle.

### 6.3.2 Check the condition of the transmission oil


#### Interval:

200 hours operating time

#### Auxiliary means:

Plastic oil dipstick, diameter approx. 5 mm

#### Procedure:

- ☑ Machine switched off and mains plug removed from socket.  
 See chapter 5.3.8 "Switch off the machine".
- ☒ Drill bit separated from machine.
- ☒ Set up the machine with the drill spindle pointing upwards and secure it against falling over.
- ☒ Remove the M10x1 screw plug (position 39 in the spare parts drawing) from the gearbox housing.
- ☒ Remove a small amount of gearbox oil from the gearbox housing using an oil dipstick.
- ☒ Check the condition of the transmission oil on the oil dipstick.  
Are many impurities visible in the transmission oil:  
Change the transmission oil.  
Gear oil to be used: Mobil Delvac Gear Oil 80W-90  
Required quantity: 0.45 liters
- ☒ Check the condition of the screw plug seal. If necessary, replace the screw plug.
- ☒ Attach the screw plug to the gearbox housing.
- ☒ After recommissioning the machine: Check the screw plug for leaks.

### 6.3.3 Replacing carbon brushes

- ① This operation must be carried out after 200 hours of operation or after the carbon brush warning system responds (red and yellow LEDs light up simultaneously and the corresponding symbol is shown on the LCD display).
- ① The carbon brushes may only ever be replaced as a pair!


#### Interval:

200 hours operating time

#### Spare part:

Set (2 pieces) of replacement carbon brushes (article number E15.66)

#### Procedure:

- ☑ Machine switched off and mains plug removed from socket.  
 See chapter 5.3.8 "Switch off the machine".
- ☑ Remove the cover (position 87 in the spare parts drawing) of the carbon brush holder (position 89).
- ☑ Remove the carbon brush (position 88) from the carbon brush holder.
- ☑ Insert a new carbon brush into the carbon brush holder.
- ☑ Attach the cover of the carbon brush holder.
- ☑ Also replace the carbon brush on the opposite side of the motor.

## 7 Troubleshooting

If a fault occurs during operation of the machine, please first try to rectify the fault yourself using the following information.


If you are unable to rectify the fault yourself, please contact Kernlochbohrer GmbH.

<b>Malfunction</b>	<b>Possible cause</b>	<b>Troubleshooting</b>
Machine does not start	Power supply interrupted	Plug in another electrical appliance and check the function of the power supply
	Mains plug not plugged in correctly.	Plug in the mains plug correctly
	Personal protection switch not reset	Press the reset button on the personal protection switch
	Loose contact on the personal circuit breaker	Have a personal circuit breaker replaced by a qualified electrician
	Power cable or on/off switch damaged	Have the mains cable or on/off switch replaced by a qualified electrician
	Rotor or stator damaged	Have it checked by a qualified electrician and replaced if necessary
	Loose contact on carbon brushes or worn carbon brushes	Clean the carbon brush spring and adjust the spring preload. If the length of the carbon brushes is less than 6 mm: Replace the carbon brushes
Leakage from water seals	Water seals worn out	Replacing water seals

<b>Malfunction</b>	<b>Possible cause</b>	<b>Troubleshooting</b>
Drill bit is stuck or jammed	Gear is not properly engaged	Turn the gear selector to the desired gear and let it engage
	Slipping clutch worn	Have the slipping clutch replaced
	High steel content in concrete or very hard material	After switching off the machine, adjust the position of the core bit slightly with a wrench and tap the tube of the core bit carefully and gently with a wooden hammer handle until the stuck core bit comes loose. Slowly pull out the core bit and restart the machine
	Gearbox damaged	Have the gearbox replaced
Drilling speed too slow	End of the service life of the drill bit reached or cutting segments broken off	Check drill bit and replace if necessary
	Too much cooling water leads to inefficient cutting of the cutting segments	Reduce water flow
	Blunt drill bit	Resharpener cutting segments
	High steel content in concrete or very hard material	Reduce the feed pressure to cut through steel or hard material. Then increase again
	Drilling angle adjusted	Realign the drilling angle so that the drill bit is perpendicular to the cutting surface
Drill spindle wobbles	Drill spindle worn	Have the drill spindle replaced

<b>Malfunction</b>	<b>Possible cause</b>	<b>Troubleshooting</b>
Flying sparks at the collector	Short circuit or interruption on the rotor coil	Have the rotor replaced
	Loose contact on carbon brushes	Clean the spring of the carbon brushes and adjust the spring preload. If the length of the carbon brushes is less than 6 mm: Replace the carbon brushes
	Commutator worn	Have the rotor replaced

## 8 Spare parts



Pos.	Article name	Qty.
1	Cheese head screw M5 x 60	4
2	Vacuum envelope	1
3	G3/4" connection piece	2
4	Sealing washer	2
5	Steel ball	2
6	Output shaft	1
7	Impact ring	1
8	Wire spring Ø28	1
9	Impact handle	1
10	Impact spring	1
11	Spring separator sleeve	1
12	Bore with stop ring Ø52	1
13	Deep groove ball bearing	1
14	Dust skeleton oil seal	2
15	Axle boot	2
16	Water ring seal	2
17	Gasket	5
18	Connecting hose	1
19	Water valve	2
20	Valve head	2
21	O-ring	2
22	Deep groove ball bearing	1
23	Output shaft	2
24	Press plate	1
25	Shaft holder	1
26	Ring	1
27	Ring	1
28	Impact tooth	1
29	Cheese head screw M5 x 30	16
30	Housing of the output shaft	1
31	Gearbox output half shaft	1
32	Axial bearing	1
33	Needle roller bearing	1
34	Paper pad	1
35	Impact tooth seat	1
36	Cheese head screw M4 x 14	1
37	Oil injector housing	1
38	Injection line	1
39	M10 x 1 screw plug	1
40	Housing	1
41	Cheese head screw M5 x 12	
42	Gear shift lever	1
43	O-ring	1
44	Earbud	1
45	Pressure seal	1
46	Axial needle roller bearing	1
47	Steel bead insert	1
48	Friction plate	2
49	Use	2

Pos.	Article name	Qty.
64	Deep groove ball bearing	1
65	Steel ball	1
66	Steel ball compression spring	1
67	Varift shaft	1
68	Gear wheel	1
69	O-ring	1
70	Flat ribbon	1
71	Sliding tooth	1
72	Gear wheel	1
73	Shaft	1
75	Oil seal frame	1
76	Deep groove ball bearing	1
77	Rotor unit	1
78	Air flap	1
79	Cheese head screw M5 x 90	2
80	Disk	4
80A	Disk	4
81	Socket	2
82	Stator assembly	1
83	Insulating jacket of the stator	1
84	Deep groove ball bearing	1
85	Rubber cover	1
86	Magnetic ring	1
87	Carbon brush cover	2
88	Carbon brush	2
89	Carbon brush holder	2
90	Disk	2
91	Motor housing	1
92	Stop screw	2
93	Wiring harness	1
94	Motor control card	1
95	Cheese head screw M4 x 16	12
96	LCD control panel	1
97	Motor control board	1
98	LCD	1
99	Pressure wire plate	1
100	Serrated lock washer	1
101	Phillips head screw	1
102	Mains plug	1
103	PRCD	1
104	Cover	1
105	Mains cable	1
106	LCD shielding	1
107	Shielding of the mains lamp	1
108	Cap screw	3
109	Rear engine cover	1
110	Handle	1
111	Cheese head screw M6 x 40	1
112	Cheese head screw M6 x 45	4

Pos.	Article name	Qty.
50	Thickening insert	1
51	Disc spring	6
52	Hexagon nut M22 x 1.5	1
53	Outer ring needle roller bearing	1
54	Gearbox sleeve	1
55	Output shaft helical gearbox	1
56	Use	3
57	Deep groove ball bearing	1
58	Triple gearbox	1
59	Binding	1
60	Bevel gear	1
61	Outer ring needle roller bearing	2
62	O-ring	1
63	Lid	1
63A	Parallel pin	1

Pos.	Article name	Qty.
113	Switches	1
114	Switch sheath	1
115	LED red	1
116	LED yellow	1
117	LED socket	2
118	Cover plate	1
119	O-ring	2
120	O-ring	1
121	Disk	1
122	Cover	1
123	Quick coupling seal	1
124	Vacuum screw connection	1
125	O-ring	1
126	Quick coupling	1
127	Airdeflector	1

## 9 EU Declaration of Conformity

The manufacturer/distributor

Kernlochbohrer GmbH  
Geigersbühlweg 52  
72663 Großbettlingen  
Germany

hereby declares that the following product

Product description: **Soft impact core drilling machine**

Type: **SID352/PRO**

complies with all relevant provisions of the applicable legal regulations (hereinafter) - including their amendments in force at the time of the declaration. This declaration of conformity is issued under the sole responsibility of the manufacturer. This declaration relates only to the machine in the state in which it was placed on the market; parts and/or modifications subsequently fitted by the end user are not taken into account.

The following legal provisions were applied:

Machinery Directive 2006/42/EU (for delivery until 2027-01-19)

Machinery Regulation (EU) 2023/1230 (for delivery from 2027-01-20)

Electromagnetic Compatibility Directive 2014/30/EU

The following harmonized standards were applied:

EN ISO 12100:2010

EN 62841-1:2015 + A11:2022

EN 62841-3-6:2014 +A12:2022

EN IEC 55014-1:2021

EN IEC 55014-2:2021

EN IEC 61000-3-2:2019 +A1:2021


EN 61000-3-3: 2013 +A2:2021

Name and address of the person authorized to compile the technical documentation:

Kernlochbohrer GmbH  
Geigersbühlweg 52  
72663 Großbettlingen  
Germany

Großbettlingen 2025-10-25

Kernlochbohrer GmbH



Guido Pillat

Managing Director / Chief Executive Officer